

Installing the **Canon i-SENSYS LBP3360** printer

NOTE: There is one important thing you need to keep in mind: the printers use **A4** paper. Now, over 90% of the time your printer is not working is because the page size is not set to **A4**, instead it is set to **Letter** (the standard American paper size), therefore, all that you need to do is go to properties / print setup, etc, search for paper size and set it to **A4**. Then it will probably work, if not, then, almost 100% of the time of that 90% of the time is because your document is still put on **Letter** format, therefore, you need to look around to set Scaling/Page scaling to **A4** in the print setup.

- Windows 7

You don't need to do anything!!! Just plug and play and **read the note above!**

- Windows Vista

Much like Windows 7, with the only strong suggestion that you should get windows 7 if you are running this operating system!!! Just plug and play and **read the note above!**

- Windows XP

You need to get the installer from the Drivers page. If you don't know how to follow the steps (they are not that intuitive), there is a tutorial that takes you step by step (with pictures) on the site, next to where you found this one :). Oh yeah and **read the note above!**

- LINUX

You have both source and documentation on the page, so enjoy reading.
Oh, and **read the note above!**

Advice: if something is not working, do check the printer screen (on the actual printer) because the error is usually self explanatory.

Also, if it says "NO LT PAPER" it means that you didn't **read the note above!**