

UNIVERSAL REMOTE USER GUIDE

**Always point the remote towards the system while using.
Make sure that the laptop/PlayStation 3/Blu-ray player are
connected properly before selecting an activity.**



ACTIVITIES: What do you want to do? Press to display a list of activities.

Press the corresponding button to select an activity

1. Watch TV (Premiere)
2. Connect laptop through VGA + Audio cables
3. Play PS3/Blu-ray through HDMI cable
4. Connect laptop through HDMI cable
5. Listen to radio

SCROLL: Press to scroll down the list of activities/options.

You can also listen to your MP3 player/iPod by plugging the audio cable and selecting Activity 2.

POWER: Turns off all the devices.

HELP: First option for troubleshooting problems.

DEVICES: Lists all the devices and allows you to control them directly.

PREV: Goes to the previous TV channel.

1. Switch off all the devices using the Power button before leaving the room.
2. Make sure to leave the remote back on the base station for charging.
3. Contact the Mercator College Office in case you need any help.